

## Thank you for buying this Cocoon and giving it a home.

All our Cocoon hanging chairs are made from premium quality materials to the highest manufacturing standards. Please read these instructions carefully. The proper installation and care of your Cocoon will ensure many years of Cocooning pleasure.

### what's in the box?

You'll find everything you need to hang your Cocoon in the box:

- 1 x Cocoon + 4m of hanging rope with steel carabiner (used to attach to the top of your Cocoon).
- 1 x set of eight aluminium Cocoon ring sections + 1 x Cocoon carry bag.

### space needed to hang your Cocoon

#### Single Ø1.5m Cocoon

**Ideal** 2.7m (headroom) / Ø2.25m (floor space)     **Minimum** 2.45m (headroom) / Ø1.6m (floor space)

#### Double Ø1.8m Cocoon

**Ideal** 2.8m (headroom) / Ø2.55m (floor space)     **Minimum** 2.45m (headroom) / Ø1.9m (floor space)

### how to put your Cocoon together

Tools required – NONE!


- 1 Place your Cocoon on the ground with the door spread open.



- 2 Build the inner ring by slotting together the sections piece by piece whilst feeding them through the guide loops on the inside of your Cocoon.




- 3 Once you have fed completed sections through all the loops complete the rest of the ring – you may have to use a bit of force to align and slot together the last two sections.



- 4 Pull the Cocoon over the completed ring – using your hands and fingers to lever the final part of the fabric over the ring (the design of the Cocoon relies on the ring fitting tightly – so be prepared to use a bit of force).



- 5 Using reef knots, secure the last parts of the inner ring to the horizontal seam with the available ties.



- 6 Hang your Cocoon – but before you do, check that the branch, beam or bracket is strong enough to take your weight and the weight of any friends who may be joining you.



## The load limit of this Cocoon is 200kg (440lbs) NEVER EXCEED THIS LIMIT

These instructions are also available in other languages which can be downloaded from our website: [www.hang-in-out.com](http://www.hang-in-out.com)

**Warranty:** All our Cocoons come with a one year warranty. Proof of purchase required.

### every time you use your Cocoon you MUST

**Always** check that your Cocoon and it's hanging system are in good condition and show no signs of damage, wear or tear.

**Always** ensure that you use a suitable knot to tie off your hanging rope and that your chosen hanging point is strong enough to take at least the same weight as you intend to have in the Cocoon.

**Never** exceed the stated load limit or hang the Cocoon higher than just above ground level (when fully laden).


**Never** jump into a Cocoon or use it as a trampoline or swing – the Cocoon is designed for gentle play and relaxation.

### how to use your Cocoon

- 1 Set the height of the ring off the ground to around that of a typical seat.
- 2 Sit down into your Cocoon just as you would if sitting down in a normal chair – you may find it helpful to use the internal rope as a handle.
- 3 Shift your body weight to suit your mood – remember the further back you move in your Cocoon the more reclined it will become.
- 4 To get out, put both feet firmly on the ground outside of the Cocoon and simply stand up just as you would if you were getting up from a normal chair – you may find it helpful to use the internal rope as a handle to pull up on.

**Never** use the ring edge as a step to get in or out of a Cocoon.

**Never** step out of a Cocoon one foot at a time – you will go one way while the Cocoon will go the other.



### how to care for your Cocoon

**Always** tether your Cocoon when not in use – this is particularly important in high winds – and ensure that it cannot bang into walls, tree trunks etc as this will damage the fabric and potentially the ring too.

**Washing** Yes, your Cocoon can be washed in a washing machine! Cold wash. No bleach. **PUT THE RING BACK INTO YOUR CACOON AND HANG DRY – DON'T DRY WITHOUT THE RING IN PLACE – DON'T TUMBLE DRY.** And don't even think about getting the iron out – Cocoons don't like irons!

Or simply wash your Cocoon down while it's hanging – use warm, soapy water and wash off with clean water.

**Disclaimer** Hang-in-out Llp and all agents and representatives thereof cannot assume responsibility for special, indirect, or consequential damages or contingent liability for use of this product in a manner not expressly intended by the manufacturer. End consumer is ultimately responsible for verifying proper installation according to our guidelines here within. We strongly recommend that you adhere to our hanging height recommendations.